

ROMA FENCE LTD.

ASSEMBLY INSTRUCTIONS FOR SPRING CLOSURE

Parts:

- 1 2-Piece Frame Collar
- 2 Nuts & Bolts for Frame Collar
- 3 2-Piece Post Collar
- 4 Hinge Bolt
- 5 Spring
- 6 Spring Tension Plate
- 7 Nuts for Hinge Bolt

Directions:

- a) Bolt two nuts onto hinge bolt with tension plate between them
- b) Place post collar on main post and fasten with assembled hinge bolt from 'step a' and a nut
- c) Assemble one frame collar on gate frame with nuts & bolts and place on hinge bolt
- d) Place spring on hinge bolt and set one prong through tension plate and other in front of gate frame
- e) Assemble other frame collar on gate frame and on hinge bolt
- f) Adjust spring tension by moving tension plate. Align gate and tighten all nuts & bolts

